



- The canopy wire fastener works fine provided you file out just very narrow notches in the canopy outline, only about 3 mm deep.
- Alternative boom installation (when you need to replace the pod, the tailplanes should not be re-installed): Cut and sand the pod so that the boom can be pushed into from the rear. Insert the boom into the pod and install all the balsa/ply bits in the canopy space. Check for correct fit. When okay, wrap the boom at the exit position with few winds of fine thread. Push into position and glue all in place.
- Probably the worst crash can occur, when the stabilizer comes off during the launch. The carbon peg will help, anyway we recommend to secure the boom/pylon/stab assembly with few loops of thread (Kevlar or similar) wrapped all around.